

# N8103-247 および iStorage NS500Rk/ NS500Rk(2nd-Gen)使用時の注意事項について

N8103-247 480GB OS ブート専用 SSD ボード(RAID1,HS)または iStorage NS500Rk/ NS500Rk(2nd-Gen)をご使用の場合で、本 Starter Pack(S8.10-013.05)を適用する際は下記をご確認ください。

Starter Pack 適用後に再起動を行い、OS 起動後もしくは POST 中に<F9>キー押下後、iLO Web インターフェイスにログインしてください。ログイン後、左側にあるメニューから「ファームウェア & OS ソフトウェア(Firmware & OS Software)」→「インストールキュー(Installation Queue)」にて、「状態(State)」が「例外(Exception)」になっているキューがないことを確認してください。「例外(Exception)」になっているキューがある場合は、本 Starter Pack(S8.10-013.05)を再度適用してください。

The screenshot shows the NEC iLO 6 web interface. On the left, the 'Firmware & OS Software' menu item is highlighted with a red box. A red arrow points from this menu item to the 'Installation Queue' tab in the top navigation bar, which is also highlighted with a red box. Below the tabs, the 'Installation Queue' table is displayed. The first row of the table has its 'State' column highlighted with a red box, showing 'Exception' with a red diamond icon. The table has three columns: 'State', 'Name', and 'Starts'.

State	Name	Starts
Exception	Universal Firmware Package for Drives - VR000480KXLXF	N/A
Pending	Online ROM Flash for Linux - Server Platform Services Manageabl	After previous tasks are executed
Pending	Wait Task for Bmc	After previous tasks are executed
Pending	Firmware Package - HPE Gen12 Boot Controller NS204i-u, HPE Gen1	After previous tasks are executed

At the bottom left of the table, there is a 'Remove all' button with a trash icon.