

大切に保管してください

N8181-98 冗長ファンキット 取り扱いの手引き

この度は、本製品をお買い上げいただきまして誠にありがとうございます。

本冗長ファンキットを本体装置へ取付ける際には本体装置に添付の「使用上のご注意」に記載されている内容をよく読んでご理解し、安全にご活用ください。

また、取り付けにあたっては、最寄りの保守サービス会社に依頼することをお勧めします。

**警告**

安全上のご注意を無視する取り扱いを行うと、装置の故障、人体事故、火災・周囲の機器の損傷を引き起こす原因となることがあります。

オプションの取り付け、取り外し時は電源プラグをコンセントから抜き、外部装置と接続しているケーブルを外してください。
故障や感電する恐れがあります。



電源プラグを抜く



感電注意

本書に記載されている場合を除き、絶対に分解したり、修理・改造を行ったりしないでください。装置が正常に動作しなくなるばかりでなく、感電や火災の危険があります。



分解禁止



発火注意



感電注意

NECN8181-98 冗長ファンキット
取り扱いの手引き

*856-129731-402-00 *

構成品

項番	品 名	数量	備考
1	冗長ファンキット 取り扱いの手引き	1	本書
2	保証書	1	
3	フロント用ファンキット	3	
4	リア用ファンキット	1	
5	フロントファンキット取り付け用 ネジセット	1	インチネジ6本

取り扱い上の注意事項

ファンを箱から取り出した後は、次の注意事項を必ずお守りください。

- ほこりの多い場所や大気中に硫黄の蒸気が発生する場所及び、水などの液体のかかるおそれのある場所に置かないでください。

ファンの取り付け

本体装置への取り付けに関しては、本体装置に添付のEXPRESSBUILDERに含まれるユーザーズガイドを参照して下さい。

第三者への譲渡

本製品を第三者へ譲渡（または売却）する場合には、本書と一緒にお渡しください。

本製品の寿命について

本製品の製品寿命は5年です。

Keep this document for future reference

N8181-98 Redundant Fan Kit Installation and Handling Guide

BEFORE INSTALLATION

Before installing this Fan Kit in your basic processing unit (including NEC Express Server), carefully read through and understand the precautions for use described in the Getting Started supplied with the basic processing unit to use the product safely. We recommend that you have your local service/maintenance center do this expansion work.



WARNING

If you disregard precautions, it may cause malfunction of the device, human body injury, fire and/or damage to the machine parts around the device.

Make sure to unplug the power plug from the electrical outlet and unplug the cables connected to external devices from the machine before installing or removing the product.

Touching the device of the NEC Express server with its power plug connected to a power source may cause an electric shock even if the NEC Express server is powered off.



Unplug the power plug.



Electric shock hazard

Never attempt to disassemble, repair, or alter the NEC Express server under any circumstances other than described in this guide. Failure to follow these instructions may cause an electric shock or fires as well as malfunctions of the server.



Prohibition of disassembly



Fire hazard



Electric shock hazard

In the Package

No.	Item	Quantity	Remarks
1	N8181-98 Redundant Fan Kit Installation and Handling Guide	1	This manual
2	Front Fan module kit	3	
3	Rear Fan module kit	1	
4	Screw set for front FAN	1	6pieces(#6-32UNC)

Precautions on Handling

Observe the following after unpacking the fan unit.

- Do not place fan unit in a place with much dust, corrosive gas in presence, or with possibilities of chemicals or liquid sprayed over.

Installing Redundant Fan Kit

Please refer to the user's guide included by sever in EXPRESSBUILDER of attachment about installation to your sever.

Transfer to Third Party

When you transfer (or sell) the Redundant Fan Kit to a third party, also give this guide to the party.

Service Life

The service life of this product is five years.