


## N8406-041 4/8G FC SFP+モジュール 取扱説明書


### 安全上のご注意

- 本製品を安全に正しくご使用になるために、ご使用前に「N8406-040/N8406-042 8G FCスイッチ ユーザーズガイド」に記載された、「使用上のご注意」を必ずお読みください。  
安全に関する重大な内容を記載しています。


### 構成品




4/8G FC SFP+モジュール



号機ラベル



保証書



取扱説明書

### 仕様

製品名	4/8G FC SFP+モジュール	
型番	N8406-041	
データ転送速度	4Gbps 8Gbps	
コネクタ	LCコネクタ	
環境条件	温度(°C) 10~35 湿度(%) 20~80	ただし、 結露なきこと

•本製品はレーザに関する安全基準(JIS C-6802,IEC825)クラス1に適合しています



**N8406-041はN8406-040/042 8G FCスイッチ専用のSFP+モジュールです。  
それ以外のスイッチへの装着はサポートしません。**

本製品の取り付け、取り外し方法につきましては「N8406-040/042 8G FCスイッチユーザーズガイド」の「4-2 SFP+モジュールの取り付け/取り外し」をご参照ください。

本製品に添付された「号機ラベル」は「N8406-040/042 8G FCスイッチユーザーズガイド」の巻末に貼付して、大切に保管してください。

N8406-041 4/8G FC SFP+モジュール  
取扱説明書

2009年 11月 初版

**日本電気株式会社**

東京都 港区 芝5丁目7番1号

TEL (03) 3454-1111 (大代表)

本書は再生紙を使用しています



\*856-128683-002-00S\*

Read this guide carefully and Keep this for your future reference.


## N8406-041 4/8G FC SFP+ Module

# User's Guide


### Precautions for Use

- Read carefully "Precautions for Use" in your "N8406-040/N8406-042 8G FC Switch User's Guide", and observe the instructions to ensure proper and safe use of this product.


### Packaging List




4/8G FC SFP+ Module



Serial Number Label



Warranty \*



User's Guide

\* This warranty is available only for using in Japan.  
Do not use it in any other country than Japan.

### Specification

Product Name	4/8G FC SFP+ Module		
Product Code	N8406-041		
Data Transfer Rate	4Gbps 8Gbps		
Type of Connector	LC-type Connector		
Operating condition	Temperature(C)	10-35	RH
	Humidity (%)	20-80	(no condensation)

**This product is classified as a CLASS 1 LASER PRODUCT.**



The N8406-041 4/8G FC SFP+ Module is used for the N8406-040 8G FC Switch (12Port) or N8406-042 8G FC Switch (24Port) . Do not install the SFP+ Module in any slot of switch modules other than the 8G FC Switch.

When you install the 4/8G SFP+ Module in the 8G FC switch, read "N8406-040/042 8G FC Switch User's Guide", "4-2. Installing/Removing SFP+ Module" .

Each FC SFP Module has a serial number label. Stick it to the label sheet in the "N8406-040/042 8G FC Switch User's Guide", and keep the sheet for your future reference.

### NEC Corporation.

7-1 Shiba 5-Chome, Minato-Ku  
Tokyo 108-8001, Japan

1st Edition  
Nov 2009

This guide is made from recycled paper



\*856-128683-002-00S\*