

K410-249(00) 内蔵SASケーブル 取り扱いの手引き


本ケーブルはデバイス増設ユニット用の内蔵SASケーブルです。
ケーブルの取り付けを行う前に準備をします。
例としてN8141-48での取り付け手順を記載します。




856-857377-001- A 2011年2月第2版

- ・デバイス増設ユニットの電源をオフにします。
- ・デバイス増設ユニットの電源コードを取り外します。
- ・プラスドライバを用意します。

プラスドライバでデバイス増設ユニットのトップカバーを外し、ネジとコネクタパネルを取り外します。
取り外したコネクタパネルとネジは使用しませんので保管しておいてください。




内側からSASケーブルをコネクタ取り付け用スロットに当て、プラスドライバを用いてネジを取り付けます。
片方のネジを緩めた状態でコネクタ側に付けておく作業が簡単に行えます。



SASケーブルにデバイスと電源ケーブルを接続し、デバイス増設ユニットのトップカバーを閉じます。

<N8141-41の場合>

装置前面のセットスクルーを緩めて、トップカバーを後方へずらし取り外します。
ケーブルの取り付けは縦向きになりますが、手順は同じです。



K410-249(00) Internal SAS Cable Handling Manual

This cable is built-in SAS cable for expanded device unit.
Preparation is necessary before installation of the cable.

* This description is install procedure of N8141-48, for example.




856-857377-001- A


February, 2011 second edition

- * Turn off the power supply of expanded device unit.
- * Detach power supply cable of the expanded device unit.
- * Prepare cross slot screwdriver.

- 1) Detach top cover of expanded device unit by the screwdriver and remove screw and connector panel. Please keep the removed connector panel and screw because they are not necessary.



- 2) Set SAS cable to connector installation slot from the inside and attach screw by screwdriver. On this occasion, it will be easy operation if the cable is attached on connector with condition of screw being loosen at one side.



- 3) Connect device and power supply cable to SAS cable, and then close top cover of expanded device unit.

<In case of N8141-41>

Loosen set screw on the front of the expanded device unit and detach top cover by shifting it.

Cable installation is vertical but procedure is same.

Binding screw (M3)

